PARTS LIST

for

Whirlpool CORPORATION

ELECTRIC DRYER

MODEL LE7700XWW0

▲W—White, N—Almond

FSP®

FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS

FSP®

Whirlpool CORPORATION
Benton Harbor, Michigan.

© 1993 WHIRLPOOL CORPORATION

12-93 Litho in U.S.A.

Part No. 4319466

12/93

TOP AND CONSOLE PARTS

For Model: LE7700XWW0



1	386367	Panel, Rear Console
2	343641	Screw, 10-16 x 1/2
3	355326	Screw, 13-16 x 5/8
4	63789	Cap, End (L.H.)
6	64211	Screw, 8-18
8	63795	Cap, End (R.H.)
10		Screen, Lint
	348851	White
	689465	Almond
13	688983	Screw, 8-18 x 5/8
16		Top
	4319449	White
	4319450	Almond
18	386635	Control Knob, Temperature
21	3393916	Timer, 60 Hz.
30	358473	Nut, Push-In (2)
31	3393997	Harness, Wiring
39	660936	Switch, Push-To-Start
	346364	(Alt.)
	692021	(Alt.)
48	3387902	Timer Knob Assembly
53	3394060	Bracket, Control
54	9830434	Panel, Control
62	688805	Clip
67	689559	Clip, Push-On (4)
72	690853	Wire, Ground
79	694720	Switch, Temperature
81	3387894	Knob, Push To Start

LITERATURE AND OPTIONAL PARTS

LITERATURE PARTS

LIT9830435	Use & Care Guide
LIT3391427	Guide, Dryer
LIT3389444	Instructions, Installation
LIT4319466	List, Service Parts

OPTIONAL PARTS NOT INCLUDED

PAINT,TOUCH UP (1/2 oz.)

72017	White
72107	Almond

PAINT PRESSURIZED SPRAY (13 oz.)

350930	White
350956	Almond
350938	Primer, Gray
350941	Leveler (Thinner)

PAINT,BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

CABINET PARTS

For Model: LE7700XWW0



1	690236	Wire, Ground (Motor)
2	9830116	Screw, 10-16 x 5/16
5	4319465	Cover, Terminal Block
6	694091	Screw
7	348365	Panel, Rear
10	347207	Switch, Door
11	98129	Screw, 6-20 x 1-3/8 (2)
12	295998	Lever, Door Switch
13	343641	Screw, Rear Panel Mounting
16	3392100	Foot, Dryer (4)
18		Cabinet
	4319451	White
	4319452	Almond
19	98234	Clip, Ground
20	18776	Lock, Front Top (2)
21		Full Front Panel Assembly
	4319436	White
	4319437	Almond
22	98669	Locator, Top
23	685203	Clip, Felt Pad
24	690081	Catch, Door
25	238614	Bumper
28	4319468	Hinge & Pin Assembly
29	3394083	Clip, Front Panel (2)
31	98997	Clip, Harness
33	696144	Strike, Door
35	4319460	Door, Rear
36		Door Front
	4319461	White
	4319462	Almond
37		Handle, Door
	4319329	White
	4319334	Almond
38	349464	Seal & Bearing Assembly
40	279393	Terminal Block Kit For Terminal Block
41	690261	Block, Terminal
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
54	3393657	Restrainer, Belt
56	3394651	Belt, Drive
57	4319454	Base, Motor
58	4319309	Screw, 5/16-18 x 3/4
59	3389627	Pulley, 60 Hz.
61	3388235	Switch (Use W/3391888 Motor)
62	3391888	Motor Assembly 60 Hz.
63	4319313	Clip, Motor
67	685762	Seal, Door
87	697776	Screw, 10-32 x 1/2 (External Ground)
88	3393008	Screw, 10-16 x 1/2
90	279318	Terminal, Tinned & Brass (3) (Includes Illus. 40)

BULKHEAD PARTS

For Model: LE7700XWW0



1	4319456	Lint Chute Assembly
2	686770	Support Protector
3	98460	Nut, Push-In (2)
4	9830337	Pad, Cabinet
5	90767	Screw, 8 x 3/8
6	3389946	Thermal, Cut-Off (Hi-Limit Thermostat Illus. No.15 Included)
7	3392247	Pad, Cabinet (Blower Housing)
8	3388703	Washer, Support
9	359702	Cap
10	694089	Wheel, Blower (Includes Illus. No. 28)
11	4319317	Housing, Blower
12	4319315	Clip
13	695239	Screw, 10-16 x 3/8
14	4319354	Box, Heater
15	3390291	Thermostat, High Limit 250~F (121.1~C) (60 Hz.)
16	339492	Washer, Support
17	660982	Element, Heater (For 240 Volt Installation)
	693300	(Alt.)
	696579	(Alt.)
	693062	(Alt.)
21	279457	Wire Kit (For Heater Element Wiring Harness Repair)
23	3392519	Fuse, Thermal
24	3387134	Thermostat, Internal-Bias
27	347139	Seal, Lint Chute
28	3392123	Seal, Blower Shaft
41	690997	Ring, Tri
42	4319306	Shaft, L.H.
43	4319304	Shaft, R.H.
44	3389901	Roller, Support
46	4319307	Washer, Support
47	120377	Nut, 3/8-16
48	4319453	Bulkhead
62	3394509	Ring, Bearing
63	690372	Screw, 11-16 x 7/8
66	4319323	Seal, Rear Drum
67	4319457	Drum Assembly
68	342847	Baffle, Drum
69	4319310	Bracket, Support
70	90296	Clip
73	339956	Seal
74	776076	Screw, 8 x 1/2 AB
75	696302	Shield, Exhaust